

21436

## SPEAKER STAND

The standard speaker stand constructed from aluminum has been significantly improved. The new legs with a tubing diameter of 35 mm and the large, fixed foot end caps guarantee stability and safety. Lasered bore holes and durable, robust plastic saddle washers improve the coefficient of friction between the legs and braces, and prevent scratching of the finish. A compact clamp with a patented push-button system affords user-friendly stand height adjustment. The locking screw provides additional stability and vibration-free speaker mount. Additional features include a pull-out guard for the extension tube and an integral anti-shock component.

### Product variant

21436-009-55 - black

### Data

<b>Height</b>	from 1,320 to 2,020 mm
<b>Height adjustment</b>	locking screw with push-button system
<b>Leg construction</b>	tube legs with cross braces
<b>Material</b>	aluminum
<b>Max. load capacity</b>	40
<b>Product Category</b>	Baseline
<b>Rod combination</b>	2-piece folding design
<b>Special features</b>	lightweight stand; patented gradual height adjustment system; integrated shock absorber; steel extension tube; mounting aid included
<b>Tube end(s)</b>	diameter 35 mm
<b>Type</b>	black
<b>Weight</b>	3.32

