



JUNO

High Quality
Inspire
Reliability
Innovative



FEATURES

- 15 to 30° beam angle, manual zoom
- Cooling by convection, in a solid housing
- Clear menu structure for DMX, stand-alone, manual operated & Master / Slave
- Wireless useable by means of a Lithium battery
- Charge via connection on the bottom and or Powercon
- Supplied with Wireless Solution, wireless DMX
- Powercon in
- Unique CLF camlock system
- 'Flicker free' for camera use
- Colourful & intense colours due to specially selected LEDs

CLF is a European brand that distinguishes itself through high-quality / innovative products. CLF products are unique because of its extremely high light output that is perfect for numerous applications. CLF stands for quality, expertise, well-considered, solid and efficient lighting solutions. CLF inspires & opens the eyes!

The CLF JUNO is the best option for in- and outdoor use, and completely wireless! This saves a huge amount of time during installation. A powerful Lithium battery ensures that the CLF JUNO can work for approx. 8 till 12 hours, on a fully charged battery. When the JUNO operates with powercable, the powercable also takes care that the Lithium battery gets charged. The internal Wireless Solution receiver allows that the JUNO can be controlled via wireless DMX (and passes DMX on). The CLF JUNO is highly suitable for events, TV Shows, and rental projects where connecting and taping many cables with several lengths costs a lot of time and energy.

SPECIFICATONS

DMX Channels	4, 6, 10, HSV, HSI Channels
Beam Angle	15 - 30° (manual zoom)
Power supply	100 - 240 VAC
Power consumption	Max. 50 Watt
Cooling	Convection / no blower
DMX connection	5p XLR in & out
Dimensions	312 x 250 x 108 mm (hxwxd)
Weight	5,5 Kg
Certification mark	CE, ROHS
Article number	156500
Included	• Power cable

