



China

3. Test results

Verdict: P = passed; F = failed; NA = not applicable; NT = not tested; NC= not checked.																		
Clause	Requirement Test	Remark	Verdict															
1	<p>Loading test</p> <p>A test load F (see below table) shall be distributed uniformly applied to the whole surface of the platform for a period of 5 minutes.</p> <p>After removal of the test load, the professional stage and flexi stage shall not show any visible damages such as cracks, indentations etc .</p> <table border="1"><thead><tr><th>Model</th><th>Platform height (mm)</th><th>F (kg)</th></tr></thead><tbody><tr><td>FX44+FX-LEG44-24</td><td>625</td><td>1000</td></tr><tr><td>FX44+FXLEG44-32</td><td>830</td><td>1000</td></tr><tr><td>FX1010+FX-LEG1010-600</td><td>620</td><td>1000</td></tr><tr><td>F1010+FX-LEG1010-800</td><td>815</td><td>1000</td></tr></tbody></table>	Model	Platform height (mm)	F (kg)	FX44+FX-LEG44-24	625	1000	FX44+FXLEG44-32	830	1000	FX1010+FX-LEG1010-600	620	1000	F1010+FX-LEG1010-800	815	1000	All models: no visible damage was found after this test.	P
Model	Platform height (mm)	F (kg)																
FX44+FX-LEG44-24	625	1000																
FX44+FXLEG44-32	830	1000																
FX1010+FX-LEG1010-600	620	1000																
F1010+FX-LEG1010-800	815	1000																

TÜV PRODUCT SERVICE LTD

Guangzhou Branch



Engineer: Filippo Wei



Technical Report Checked: Koby Liang

TÜV Product Service Ltd. Guangzhou Branch

TÜV SÜD Group

26/F, Dongbao Tower, 767 Dongfeng Road East

Guangzhou, P.R. China, 510600

Tel.: +86 20 3832 0668

Fax: +86 20 3832 0478

Technical Report No. 64.190.09.052.01

Engineer: Filippo Wei

2009-08-06

Page 5 of 5

Report No.: 64.190.09.052.01
Photo documentation of testing

Type of equipment, model:

Flexi stage: FX44+FX-LEG44-24, FX44+FXLEG44-32,
FX1010+FX-LEG1010-600, F1010+FX-LEG1010-800

Details of: FX1010+FX-LEG1010-600, Load: 1000 kg

View:

- general
- front
- rear
- right
- left
- top
- bottom



Details of: F1010+FX-LEG1010-800, Load: 1000 kg

View:

- general
- front
- rear
- right
- left
- top
- bottom



Details of: FX44+FX-LEG44-32, Load: 1000 kg

View:

- general
- front
- rear
- right
- left
- top
- bottom



Details of: FX44+FX-LEG44-24, Load: 1000 kg

View:

- general
- front
- rear
- right
- left
- top
- bottom

