



Audiology 3 Charging unit

L 2015

Cat. No. 09828 **Description**

The L 2015 quick-charging unit automatically recharges two Sennheiser BA 2015 rechargeable battery packs. The battery packs are either inserted directly into the charger or remain in their bodypack transmitters/receivers of the 2015 System or the evolution wireless G2 300 and 500 Series.



Delivery includes

1 L 2015 charging unit Operating instructions

Recommended Accessories

Mains unit for ASP 1 (120V version) Mains unit for ASP 1 (UK version) Plug-in mains unit for AC 1 (EU version) Plug-in mains unit for AC 1 (120V version) Plug-in mains unit for AC 1 (120V version) Plug-in mains unit for the NT 3-UK Cat. No.04788 Cat. No.04787 Cat. No.04863 Cat. No.04863	Mains unit for ASP 1 (EU version)	NT 1	Cat. No.04786
version) Plug-in mains unit for AC 1 (EU version) Plug-in mains unit for AC 1 (120V version) NT 3 Cat. No.04863 Cat. No.04865	•	NT 1-120	Cat. No.04788
(EU version) Plug-in mains unit for AC 1 (120V version) NT 3-120 Cat. No.04865	•	NT 1-UK	Cat. No.04787
(120V version)	•	NT 3	Cat. No.04863
Plug-in mains unit for the NT 3-UK Cat. No.04864	3	NT 3-120	Cat. No.04865
AC 1 (UK Version)	Plug-in mains unit for the AC 1 (UK Version)	NT 3-UK	Cat. No.04864

Features

Convenient quick-charging

Charging unit recognizes a fully charged battery and automatically switches to trickle charging Temperature and voltage are monitored for increased safety

Bodypack transmitters/receivers are automatically switched off when they are inserted into the L 2015 Long battery life due to overcharge protection and regeneration of exhausted batteries

Automatic fault detection

Several charging units can be daisy-chained and powered by one power supply unit

Technical data

Input voltage range	1020 V DC
Current consumption	400750 mA
Output voltage	2x 2,9 V
Power supply	2x 700 mA
Cells	NiMH, 2x 1,2V (BA 2015)
Charging time	ca. 2,5 h
Operating temperature	040 °C
Dimensions	145 x 80 x 110 mm
Weight	310 g