

IXOLIFT X400

ADJUSTABLE WORK PLATFORM

- Simple and safe to use
- Working height up to 4 meters
- Safety compliant alternative to ladders
- Compact sized, easy to move around alone
- Automatic anti-surfing brakes for extra safety
- Patented gas spring powered height adjustment
- Eco friendly, hydraulic oil free, maintenance free
- Options: ATEX rating, Stainless steel version, Tool tray



TECHNICAL SPECIFICATIONS	IXOLIFT X400W	IXOLIFT X400WS
Working height	3974 mm	
Max working load	150 kg	
Max platform height	1974 mm	
Min platform height	974 mm	
Platform size	526 x 556 mm	
Stowed height	1970 mm	
Stowed length	1198 mm	
Stowed width	728 mm	
Total weight	230 kg	
Max length with stabilisers out	N/A	1500 mm
Max width with stabilisers out	N/A	1668 mm
Wind rating	0 m/s	12,5 m/s
CE Marking	Machinery Directive 2006/42/EC EN 280:2013 + A1:2015 except §5.6.2 Guardrails based on EN 131-7 §5.6	
ATEX Marking (Optional)	ATEX Directive 2014/34/EU Ex h IIC T6 Gb & Ex h IIIC T60°C Db	

PATENTED



Compact size



Automatic brakes



Gas spring powered



Tool tray



IXOLIFT Ltd | Tillinmäentie 3 B 118 | FI-02330 Espoo, FINLAND
+358 20 741 5010 | sales@ixolift.com | www.ixolift.com

IXOLIFT X500

PUSH IT OR DRIVE IT HYBRID INVENTION

Drive it or Push it, your choice!

- Automatic brakes
- Low maintenance
- Working height up to 5 meters
- Fits through doorways and in elevators

TECHNICAL SPECIFICATIONS	IXOLIFT X500E-SP	
Working height	4950 mm	
Max working load	180 kg	
Max platform height	2950 mm	
Platform size	530 x 760 mm	
Guardrail height	1100 mm	
Stowed height	1640 mm	
Stowed length	1200 mm	
Stowed width	760 mm	
Total weight	320 kg	
Driving speed	Raised, 2 km/h	Lowered, 4 km/h
Lifting speed	16 s	
Power source	2pc, 75 Ah, 12V batteries, maintenance free	
Wheels	Polyurethane coating, leaves no marks	
CE Marking	Machinery Directive 2006/42/EC EN 280:2013 + A1:2015	



Decoupling



USB Socket



Self-Propelled



Push Around

2019 / v1.02



IXOLIFT Ltd | Tillinmäentie 3 B 118 | FI-02330 Espoo, FINLAND
+358 20 741 5010 | sales@ixolift.com | www.ixolift.com