

# MA-303du Personal Wireless PA System



## Ultra Light, Ultra Compact, Ultra Portable

Don't be misled by the compact, A4 size of this highly portable, personal sound system. Lightweight, robust and battery operated, it can be carried via the built-in handle, onto any flat surface or mounted on a microphone stand for all situations where you need to raise the volume of your voice to communicate with small to medium audiences.

## Industry's Easiest and Fastest Channel Set-up!

AutoScan and ACT™ (Automatic Channel Targeting) infrared sync are industry's first technology from MIPRO in 2000. One touch scans an open, interference-free receiver frequency. One touch ACT syncs the transmitter and receiver frequency automatically.

## Ideal Applications

Ideal for use in classrooms, day-care activities; playground duty, wedding ceremony & reception; corporate meetings, seminars & presentations; places of worship, shopping center presentation paging, fire fighters, law enforcement, search & rescue squads or any outdoor/indoor location where good quality speech announcements are a requirement.

## Key Features

- Ultra light, ultra compact & ultra portable.
- Powerful 60-watt for loud, clear sound projection.
- High efficiency class-D amplifier drives 2-way, 5" woofer & 1" tweeter loudspeakers.
- 2 power modes: AC and rechargeable battery.
- Up to 16 hours of standby time per 4 hours charge.
- For crowds up to 300.
- Built-in 1 or 2 wireless diversity receivers for reliable, extended reception range.
- 16 preset scannable frequencies.
- One-touch Scan & ACT IR sync for easy & quick channel set-up.
- Optional USB music player & recorder with LCD screen. Remote control included.
- Line-input accepts an external iPod, MP3 or CD player.
- Line-output for external recordings.
- Microphone input for 1 wired dynamic microphone.
- 4 LED indicators for accurate battery levels and charging status.
- Built-in alarm siren provides emergency warnings.
- Integrated microphone stand mount.
- Rechargeable lithium battery is included.



Specifications subject to change without notice

# MA-303du Personal Wireless PA System



MA-303s



MA-303su



MA-303d



MA-303du

## System Configurations

- **MA-303s** Single-Channel. No USB player & recorder
- **MA-303su** Single-Channel + USB player & recorder
- **MA-303d** Dual-Channel. No USB player & recorder
- **MA-303du** Dual-Channel + USB player & recorder

## Transmitters / Microphones

- **ACT-30H** Handheld Transmitter Microphone
- **ACT-30T** Bodypack Transmitter
- **MU-53L/55L** Uni/Omni-directional Lavalier Mics
- **MU-53HN/55HN** Dual-sided Uni/Omni-directional Headset
- **MU-210/MU-23** Dual-sided Uni/Omni-directional Headset
- **MU-13** Single-sided Omni-directional Headset

## Optional Accessories

- **MB-10** Replacement Rechargeable Lithium Battery
- **SC-30** Storage and Carry Bag
- **MM-107** Wired Dynamic Microphone
- **MS-30** Tripod Microphone Stand

## Technical Specifications

AF Power Output:	60-Watt Maximum
Amplifier:	Class D
Frequency Response:	50 Hz ~18 kHz
Mic Input:	6.3mm / 1/4"
Battery Type:	Rechargeable Lithium 14.8V/2.6AH (included)
Operating Time:	9~12 standby hours per 4 hours charge
Receiver Channels:	UHF 16 auto-scannable channels
T.H.D.:	< 1%
Speaker:	5-inch woofer, 1-inch tweeter
Line Input:	3.5mm / 1/8"
Line Output:	3.5mm / 1/8"
Power Supply:	Built-in 14.8V/2.6AH rechargeable battery (MB-10), charger & 100~240V AC switching power supply
Dimensions:	210(W) × 276(H) × 165(D) mm 8.3(W) × 11(H) × 6.5(D) "
Approx. Weight:	MA-303s: 2.7 kg / 6 lbs MA-303su: 2.8 kg / 6.2 lbs MA-303d: 2.7 kg / 6 lbs MA-303du: 2.8 kg / 6.2 lbs
Color:	Black (standard), White (optional)

Specifications subject to change without notice