MM-202P Mini-gooseneck Microphone

Introduction

Mini-gooseneck Microphone. Can be used as a handheld microphone or lavalier microphone when connected to a MTG-100T or MTG-100a portable digital transmitter worn with a neck lanyard for tour guide or language interpretation applications.

Key Features

- Ultra slim profile design for podiums, pulpit and lectern applications.
- Proprietary microphone mount design allows 110° up/down and 300° left/right angle adjustments.
- Shock isolation mount design minimizes handling and vibration noise.
- Multi-layered microphone grill minimizes pop noise.
- Unmatched high fidelity sound reproduction.
- MM-202P is designed to fit MTG-100T or MTG-100Ta portable digital transmitter and used as a handled microphone or lavalier microphone and worn with a neck lanyard for tour guides or language interpretation applications.

Transmitter

MTG-100T	Digital Portable Transmitter (Rechargeable Battery)
MTG-100Ta	Digital Portable Transmitter (AA Battery)

Technical Specifications

Capsule Module	10 mm uni-directional condenser microphone
Frequency Response	50 Hz – 18 kHz
Maximum SPL	136 dB (Typical, 1% T.H.D.)
Sensitivity	-46 dBV ± 3 dB at 1 kHz (0 dB=1 V / Pa)
Plug	3.5 mm mini jack screw-lock
Length	136 mm / 5.4 "
Weight	Approx. 22 g / 0.8 oz





