

ScreenBeam 1100

4K wireless display and collaboration

Designed for organizations requiring a high performing 4K universal wireless display and collaboration solution with multi-network support. Combining local Wi-Fi mode connectivity with industry standard Miracast™, and dual-network infrastructure connectivity with network bridge functionality, delivers unparalleled deployment options for employee and guest wireless presentations.

ScreenBeam 1100 delivers easy, app-free universal wireless screen sharing across multi-network enterprise configurations for employee and guest devices. Support for native screen mirroring functionality in Windows, Apple, Android and Chromebook devices eliminates downloading an app, or searching for the right AV cable, HDMI or DisplayPort adapter.

Windows and macOS users can share content in both duplicate and extended screen modes, and support for interactive touch displays and Windows Ink brings collaboration to the front of room display. ScreenBeam 1100 delivers an affordable, easy user experience, with advanced technology to provide simplicity and scalability for deployment and management.



CATALOG NUMBERS
SBWD1100
 ScreenBeam 1100
 Wireless Display Receiver
 with ScreenBeam CMS

Every ScreenBeam 1100 includes Central Management System (CMS) software to remotely manage large-scale deployments across multiple locations, saving time and money.



[Learn More](#)

Key Features

- ✓ Present from laptop, tablet or smartphone wirelessly
- ✓ Native screen mirroring solution; no app, no dongle
- ✓ Flexible in-room display sharing preference
- ✓ True extended desktop mode support
- ✓ Swift switching between presenters
- ✓ Optional secured and isolated Wi-Fi hotspot
- ✓ Windows 10 native wireless touch and inking
- ✓ Integrated HTML-based digital signage player
- ✓ Designed for enterprise complex network environments
- ✓ Flexible multi-network for staff and guest presenters
- ✓ Up to four users onscreen sharing
- ✓ 4K and interactive touch panel ready

Technical Specifications

ScreenBeam | 1100

Compatible OS/Device

Miracast P2P wireless display requires certified device with either:

- Windows 10 build 1607 (and later) or Windows 8.1
- Android 4.2 (and later)

Wireless display over network requires device with either:

- Windows 10 build 1709 (and later)
- Windows 7 (and later)
- macOS 10.10 (and later)
- iOS 11 (and later)
- Chrome OS 74.0.3729.159 (and later)

Language Support

English, Simplified Chinese, Traditional Chinese, Japanese, French, German, Dutch, Korean, Spanish, Italian, and Russian

Hardware Specifications

Video	H.264 compression	
Audio	LPCM 2.0	
Resolution ¹	Up to 4K60 (HDMI), 4K30 (Windows 10 Miracast)	
Ethernet	10/100/1000-BASE-T RJ-45 LAN	
Wireless	Miracast and Local Wi-Fi Mode: 802.11ac dual-band 3x3 MIMO Network Bridge: 802.11ac dual-band 2x2 MIMO	
Authentication	WPA-PSK (TKIP)	
Protocol	WPA2-PSK (AES), PEAP-MSCHAP V2, EAP-TLS	
Interfaces	1 x HDMI Output	2 x USB 2.0 Host Type-A
	1 x VGA Output	1 x USB 3.0 Host Type-A
	1 x Analog 3.5mm audio Output	1 x DC Power Jack
Content Protection ²	HDCP 2.x	
Power	Input: 12VDC, 3A Consumption: 8.4W (typical), 36W (peak)	
Dimensions	8.66 x 5.66 x 1.99 inch (220 x 144 x 50.5 millimeter)	
Temperature	Operating: 0° – 40° C (32° – 104° F), Storage: -20° – 85° C (-4° – 185° F)	
Humidity	Operating: 20 – 80% non-condensing, Storage: 10 – 90% non-condensing	

Regulatory and Compliance

North America	FCC and UL
European Union	CE, RED, and RoHS

Warranty

Two years

Industry Leader

ScreenBeam Inc., a leading wireless display and collaboration provider, delivers an app-free screen sharing experience on any modern device to bring intuitive wireless collaboration into any meeting space or classroom. ScreenBeam is Microsoft's co-engineering partner for wireless display enabling wireless Office 365 experiences.

ScreenBeam solutions are used as the validation platform for wireless display functionality by companies like Microsoft and leading PC OEM and device companies. Headquartered in Santa Clara, CA, ScreenBeam has offices across the United States, Europe and Asia.

screenbeam.com

1. Actual display resolution and quality depend on the wireless/network environment

2. Content protection is not available for macOS/iOS

© 2020 All rights reserved. ScreenBeam and the ScreenBeam logo are registered trademarks owned by ScreenBeam Inc. All other names are properties of their respective owners. Specifications subject to change without notice. 012720



ScreenBeam®