

# SM-32 Saxophone Microphone Set

## Introduction

The MIPRO SM-32 saxophone microphone set has been designed after years of collaborating with professional musicians. Three detachable wide dynamic range condenser microphone capsules, MU-10, MU-16 and MU-20, together with a gooseneck clip, offer optimal flexibility for performers and instruments. A shock-proof microphone module is connected to a gooseneck for minimizing handling and hitting noises. Simply integrate the SM-32 to the SH-32 and strategically place it in a position that picks up the accurate sound of the instrument. The SM-32 is easy to use, install or remove, protecting the instruments from surface scratches.

## Microphone Modules

<b>MU-10</b>	Ø 10 mm Cardioid Capsule Module
<b>MU-16</b>	Ø 16 mm Semi-supercardioid Capsule Module
<b>MU-20</b>	Ø 20 mm Supercardioid Capsule Module

## Accessory

<b>SH-32</b>	Saxophone Microphone Clip
<b>SC-32</b>	Saxophone Microphone Cable

## Technical Specifications

Output Jack	Mini XLR male
Dimensions (Ø × L)	15 × 189 mm / 0.6 × 7.4 "
Weight	Approx. 33 g / 1.2 oz, excluding microphone modules



### MIPRO Electronics Co., Ltd

Headquarters: 814 Pei-kang Road, Chiayi, 60096, Taiwan  
Tel: +886.5.238.0809 | Fax: +886.5.238.0803  
www.mipro.com.tw | mipro@mipro.com.tw