

SUBLIME-BL

Ultra compact passive 6.5" dual coil subwoofer, black



The SUBLIME is an ultra compact passive 6.5" dual coil subwoofer that offers the ultimate blend of a compact size and deep, fat basses. Thanks to the built-in X-over, this subwoofer is the ideal partner for the MASK2 top speakers.

This thinnest subwoofer on the market (only 12 cm deep) allows for easy integration into any interior: on the wall (mounted with the included wall mounting brackets), behind curtains or even under furniture. Speaker and connection terminals are invisible when mounted on the wall using the included mounting brackets.

It may look like a small heating radiator, but instead of heat, it will radiate musical vibes in your room.

The SUBLIME subwoofer has a built-in stereo X-over filter, thus eliminating the need for external filters. The X-over filter separates the high frequencies and sends them directly to the top speakers. Optionally, you can use the SUBLIME speaker in an active speaker setup, using an active filter and separate power amplifier. You can use the SUBLIME up to 200 Hz.

TECHNICAL SPECIFICATIONS

height in mm	420	width in mm	470
depth in mm	120	loudspeaker system	dual coil
woofer size in inch	8	woofer cone material	paper
mounting system	wall bracket	colour	black / white
impedance in ohms	8	low impedance power in watts	2 x 80
SPL 1W/1m in dB	85	max SPL 1m in dB	107
frequency response in Hz	50 - 200	main construction material	mdf wood
grille main material	cloth	IP rating	20
applicable low impedance	Yes	applicable in 100V	No

MORE PICTURES

