



KRAMER

VS-211UHD

4K UHD HDMI Auto Switcher



The VS-211UHD is a high-performance automatic switcher for 4K UHD HDMI and analog audio signals. The unit automatically switches to a predefined or the last connected input whenever the currently active video signal is interrupted or whenever a higher-priority video signal is detected.

FEATURES

- Max. Data Rate - 8.91Gbps (2.97Gbps per graphic channel) with 4K UHD support.
- HDTV Compatible.
- HDCP and HDMI Compliant.
- HDMI Support - Deep Color, ARC, up to 7.1 Uncompressed Audio Channels, CEC.
- DVI 1.0 Support.
- Automatic Input Detection & Selection.
- Auto-Power Off - When no HDMI input for 10sec (selectable).
- HDCP On/Off Switching.
- EDID Configuration Options.
- Selectable Switching - Manual or fast auto switching according to last connected or preset priority.
- Step-in Functional Support.
- Contact Closure - For remote manual switching override.
- HDMI ARC De-Embedding - From output to balanced stereo audio line out uncompressed.
- Firmware Upgrade - Over mini-USB, RS-232.
- Software Support - For Protocol 3000, EDID Designer, K-Upload.
- Varied Control Options - Front panel buttons, contact closure, IR, RS-232 Protocol 3000.

