

WiPG-1000

Our entry-level model is affordable and packed-full with features. The **WiPG-1000** is perfect for classrooms, meeting rooms, and small huddle spaces.



SPECIFICATIONS

Processor	800MHz
Standards	IEEE 802.11b/g/n 2.4GHz IEEE 802.3 (10BASE-T), IEEE8023u (100BASE-TX)
Security	IEEE Standard 64/128 bit WEP/WPA/WPA2-PSK
Management	Web-Based ADMIN Panel Configuration
Output Resolutions (VGA)	SVGA (800x600), XGA (1024x768), WXGA (1280x768), WXGA (1280x800), WXGA (1360x768), WXGA+ (1440x900), UXGA (1600x1200)
Output Resolutions (HDMI)	720p (1280x720), 1080i (1920x1080), 1080p (1920x1080)
Supported Windows Operating Systems	Windows XP, Vista, 7, 8, 8.1
Supported OS X Operating Systems	Mac OS X 10.5 and above
Supported Mobile Operating Systems	Android 2.2 and above, iOS 3.2 and above
Power	External power adapter (DC 5V 2.6A)
Onboard Interfaces	15Pin VGA USB 2.0 (x3) HDMI Reset Button RJ-45 Stereo Phone Jack
Certificate	FCC / CE



TOP FEATURES OF THE WiPG-1000

- ✓ 1080p Cross Platform Wireless Presentations
- ✓ Built-In Wireless Access Point (WAP)
- ✓ Conference Control / Moderator Control

Find more at: www.wePresentWiFi.com/features



MirrorOp Sender

Fully mirror content from Galaxy devices to your display for wireless presentations (BYOD).



MirrorOp Presenter

Wirelessly present documents, photos, video, webpages, and 3D objects from iOS devices to your display.



Windows Support

Mac Support

iOS Support

Android Support

BASIC FEATURES:



Cross Platform

Windows. Macbooks. iOS. Android. Connect it all Wirelessly. With wePresent, BYOD meets wireless projection.



64-User Queue

Up to 64 users can connect to the wePresent gateway making it a truly collaborative experience.



1080p Resolution

With both an onboard VGA and HDMI video output, you can let classroom and conference room users wirelessly project in resolutions up to full 1080p.



Quadrant Display

Allows users to project up-to 4 devices onscreen at the same time, and wirelessly collaborate in real time.



LAN Port

If wePresent is hardwired to your network, users can connect to your network as usual to wirelessly present and still maintain internet.



30fps

wePresent allows video mirroring at up to 30-frames-per-second for smooth video playback

ADDITIONAL FEATURES:

Customized Logo on Standby Screen

Add a company logo to brand the standby screen, so it's the first thing users see.



Wireless Access Point

wePresent functions as a wireless access point, allowing internet access.



WebSlides

To view the projecting screen from web browser on any device.



Conference Control

Mediator function through the device web page or standby. Support up to 64 users



SidePad Mobile Control

SidePad receiver for Android/iOS to operate Windows/Mac from mobile device.



USB Guest Access

launching the projection application from a USB thumb drive without installation.

