R22-WP-X



The R22-WP-X is a wall-mount Dante interface panel within the Xilica Rio family of networked audio products. The R22-WP-X provides a cost-effective way to add two (2) I/O channels of bi-directional Dante audio to an existing Dante-based network.

The R22-WP-X provides XLR analog I/O connections only, alongside Mic/Line input, switchable 48V Phantom power and separate status LED. The product features a two-piece design with Decorastyle faceplate, which snaps onto the main metal body. Variants are available in all black, all white, black/white and white/black.

R22-WP-M



The R22-WP-M is a wall-mount Dante interface panel within the Xilica Rio family of networked audio products. The R22-WP-M provides a cost-effective way to add two (2) I/O channels of bi-directional Dante audio to an existing Dante-based network.

The R22-WP-M provides a mix of XLR, dual RCA (L+R summed), and stereo 3.mm (L+R summed) analog connections, alongside switchable 48V Phantom power. The product features a two-piece design with Decora-style faceplate, which snaps onto the main metal body. Variants are available in all black, all white, black/white and white/black.

Specifications

Input impedance >10k Ohms
Output impedance 50 Ohms

Maximum level +20dBu (mic gain: 0 / +40dB steps)

Type Electronically balanced (w/48V Phantom)

Frequency response +/- 0.1dB (20 to 20kHz)

Dynamic range 110dB typ (unweighted)

CMMR > 100db (50 to 10kHz)

Crosstalk < -100dB

Distortion 0.002% (1kHz @ +4dBu)
Analog converters High performance 24-bit

Sampling rate 48kHz

Recessed switches

Select Mic/Line Input, 48V Per Input

Status LEDs

(1) Panel Power, (1) Mic Input, (1) 48V

Signal connectors

Dual XLR I/O (R22-WP-X); XLR; RCAs

Colour variants

Black, White, Black/White, White/Black

Power 12VDC (included) or PoE

Surface mount backbox Included

Dimensions (WxHxD) 108mm x 45mm x 152mm

4 1/4" x 1 3/4" x 4 3/4"

Weight 1/2lbs /227 grams

Physical design Decora-style front panel w/RJ45 (Dante)



Customer Support

If you'd like to contact us regarding product support or technical designs, email support@xilica.com and we'll connect you with a solutions engineer. Alternatively, if you'd like to speak to someone, you can call the following numbers for immediate assistance:

North America & Rest of World: +1 905-770-0055

Europe: +31 29940-1100

China & Hong Kong SAR: +852 2604-9382

