



BEAMZ
MADE
EAZY

151.381 V1.1

BTF300Z

QUICK START GUIDE

CONTROL MENU

MENU		DESCRIPTION		
DMX ADDR	d001-d512		DMX address setting	
MODE	DMX	1 / 2 / 3 / 4 Ch	DMX channel mode	
	Auto	Program	001-008	Preset programs
		Speed	001-009	Programs speed
	Manual	Brightness	000-255	Dimmer 0-100%
		Strobe	000-255	Strobe, slow to fast
		Zoom	000-255	Zoom from wide to narrow
DIMMER	Curve	0.3-3.0	Dimmer curves adjustment	
	Mode	Standard		Select dimmer curve
		Stage		
		TV		
		Architecture		
		Theatre		
		Studio		Studio Power mode - Silent
Custom	Fade in (150ms-2230ms) Fade out (150ms-2230ms)			
ADVANCE	Authorization	On / Off	Advanced settings for Beamz support only.	
	Signal priority	DMX		
		ArtNet		Signal priority setting
	Signal hold	On / Off	Run if signal cut	
	RDM	On / Off	RDM function on / off	
	Screen Timeout	30sec.		Display shut off time
		Never		
	Screen brightness	25-100%		Display brightness
	Dimming Freq	1.2KHz		Dimmer frequency setting
		1.6KHz		
2.4KHz				
4KHz				
6KHz				
20KHz				
24KHz				
RESET	Yes / No		System reset	
REVERSE	Yes / No		Display reverse 180°	

DMX CHANNELS

1 CHANNEL

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Dimmer	000-255	0-100% Dimmer

2 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Dimmer	000-255	0-100% Dimmer
2	Zoom	000-255	Zoom from wide to narrow

3 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Dimmer	000-255	0-100% Dimmer
2	Strobe	000-255	Strobe from slow to fast
3	Zoom	000-255	Zoom from wide to narrow

4 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Dimmer	000-255	0-100% Dimmer
2	Dimmer fine	000-255	0-100% Dimmer fine
3	Strobe	000-255	Strobe from slow to fast
4	Zoom	000-255	Zoom from wide to narrow

TECHNICAL SPECIFICATIONS

Rated voltage	: 100-240VAC, 50-60Hz, 1.1-2.3A
LED	: 300Watt
Beam angle	: 8-60°
Illuminance	: 137.000lx @1m
Flash rate	: 1-20Hz
Fuse	: F5A
DMX Channels	: 1, 2, 3, 4
Functions	: DMX, RDM, manual
Dimensions per unit	: 320 x 280 x 490mm
Weight (per unit)	: 9,20kg

Design and product specifications are subject to change without prior notice.

European Union

Tronios B.V.,
Bedrijvenpark Twente Noord 18,
7602KR Almelo, The Netherlands

2014/35/EU
2014/30/EU
2011/65/EC



United Kingdom

Tronios Ltd.,
130 Harley Street,
London W1G 7JU, United Kingdom

S.I. 2016:1101
S.I. 2016:1091
S.I. 2012:3032





BEAMZ

**YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT**



offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!

