



**BEAMZ**  
**MADE**  
**EAZY**

155.108 V1.0

**BTK200C**

**QUICK START GUIDE**

# CONTROL MENU

| MENU             |                         | DESCRIPTION  |
|------------------|-------------------------|--|
| <b>DMX06 OK</b>  | 001-512                 | “OK” represents signal received;<br>“! ” represents no signal received;<br>“DMX06” represents current channel is channel 6;<br>“DMX02” represents current channel is channel 2.                        |
| <b>DMX CHX</b>   | 06CH<br>02CH            | 06ch: Channel 6<br>02ch: Channel 2   |
| <b>WORK MODE</b> | DMX<br>Rotate<br>Manual | Dmx512 console dimming mode<br>Potentiometer dimming mode<br>Manual dimming mode   |
| <b>LED CCT</b>   | 4000K                   | Under manual mode, the CCT selected 2800k → 6000k  |
| <b>DIMMER</b>    | 100%                    | Under manual mode, the dimmer selected 000% → 100%   |
| <b>WW</b>        | 100%                    | Under rotate mode, console Warm White to select low CCT luminance (0%-100%)  |
| <b>CW</b>        | 100%                    | Under rotate mode, console Cool White to select high CCT luminance (0%-100%)   |
| <b>LED MODE</b>  | Smooth / Fast           | Smooth: smooth dimming<br>Fast: fast dimming   |
| <b>LCD BACK</b>  | Off / Open              | Off: display turned off automatically after 30s without button operation<br>Open: display always on  |
| <b>FAN MODE</b>  | High / Auto             | High: cooling fan is working at high speed<br>Auto: cooling fan is working in intelligent mode, the corresponding operation will be turned on automatically when reaching the appropriate temperature. |
| <b>LED TEMP</b>  | 060C                    | Temperature in Celsius   |

# DMX CHANNELS

## 6 CHANNELS

| CHANNEL | FUNCTION           | VALUE   | DESCRIPTION  |
|---------|--------------------|---------|--------------|
| 1       | DIMMING            | 000-255 | 0 → 100%     |
| 2       | STROBE             | 000-255 | Slow → Fast  |
| 3       | LOW CCT            | 000-255 | 0 → 100%     |
| 4       | HIGH CCT           | 000-255 | 0 → 100%     |
| 5       | 0                  | 000-039 | Standard CCT |
|         | 2800K              | 040-079 |              |
|         | 3200K              | 080-119 |              |
|         | 4000K              | 120-159 |              |
|         | 4800K              | 160-199 |              |
|         | 5600K              | 200-239 |              |
|         | 6000K              | 240-255 |              |
| 6       | LOW CCT → HIGH CCT | 000-255 | No polar CCT |

## 2 CHANNELS

| CHANNEL | FUNCTION           | VALUE   | DESCRIPTION  |
|---------|--------------------|---------|--------------|
| 1       | DIMMING            | 000-255 | 0 → 100%     |
| 2       | LOW CCT → HIGH CCT | 000-255 | No polar CCT |



# BEAMZ

**YOUR FUTURE**  
**YOUR SKILLS**  
**YOUR PLATFORM**  
**YOUR PARTY**  
**YOUR EVENT**



offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!

