# TRI-O

**U**SER MANUAL



# **Safety instructions**


- 1 All safety instructions, warnings and operating instructions must be read first.
- **2** All warnings on the equipment must be heeded.
- **3** The operating instructions must be followed.
- **4** Keep the operating instructions for future reference.
- The equipment may never be used in the immediate vicinity of water; make sure that water and damp cannot get into the equipment.
- The equipment may only be installed or fitted in accordance with the manufacturer's recommendations.
- 7 The equipment must be installed or fitted such that good ventilation is not obstructed in any way.
- The equipment may never be installed in the immediate vicinity of sources of heat, such as parts of heating units, boilers, and other equipment which generates heat (including amplifiers).
- 9 Connect the equipment to a power supply of the correct voltage, using only the cables recommended by the manufacturer, as specified in the operating instructions and/or shown on the connection side of the equipment.
- 10 The equipment may only be connected to a legally approved earthed mains power supply.
- The power cable or power cord must be positioned such that it cannot be walked on in normal use, and objects which might damage the cable or cord cannot be placed on it or against it. Special attention must be paid to the point at which the cable is attached to the equipment and where the cable is connected to the power supply.
- **12** Ensure that foreign objects and liquids cannot get into the equipment.
- 13 The equipment must be cleaned using the method recommended by the manufacturer.
- 14 If the equipment is not being used for a prolonged period, the power cable or power cord should be disconnected from the power supply.
- In all cases where there is a risk, following an incident, that the equipment could be unsafe, such as:
  - · if the power cable or power cord has been damaged
  - if foreign objects or liquids (including water) have entered the equipment
  - if the equipment has suffered a fall or the casing has been damaged
  - if a change in the performance of the equipment is noticed

it must be checked by appropriately qualified technical staff.

The user may not carry out any work on the equipment other than that specified in the operating instructions.



# **Dateq TRI-O**



The DATEQ TRI-O is a six channel 19-inch 3-zone mixer. It is highly suitable for use in pubs, dancing-schools, conference centres etc. The TRI-O is equipped with three microphone inputs and 8 stereo-line inputs. The inputs can be routed to the 3 master outputs.

Channel 1 has a talk-over circuit to improve the speech intelligibility. This circuit, which is triggered by the microphone signal from channel 1 (i.e. it is voice-activated), ensures that this signal overrides all others. The talk-over function can be disabled with the TalkOver switch on the front.

By default three output zones are available (master A, B and C). These zones have a dual equaliser, balance and gain-control. In addition a maximum of four output modules (output zones) may be added. The volume of these additional zones is externally adjustable with a potentiometer CREWXOUT-W / CREWXOUT-B (not included) or an external regulation voltage.



The master outputs are electronically balanced on XLR and unbalanced on cinch connectors. The balanced output makes it possible to use long signal-cables so that the amplifiers can be placed near to the speakers. The optional output zones are equipped with unbalanced cinch connectors.

Channel 2 has a connection for a Musicall local line input, MRA-2WW or MRA-2GG. (not included)





# **Product support**

For questions about the TRI-O, accessories and other products, please contact:


### **Dateq International BV**


De Paal 37 1351 JG Almere The Netherlands Phone: +31 36 54 72 222
E-mail: info@dateq.nl
Internet: www.dateq.nl

# **Installing the TRI-O**

The TRI-O is designed to be mounted in a 19-inch rack and is three units high. The cabinet fits into an opening of  $445 \times 132 \times 110 \text{ mm}$  (W x H x D). See also the dimensioned drawings below.


The 19-inch mounting bracket is 2mm thick. When installing the mixer, remember to allow sufficient room for the connectors and plugs on the Crew's rear!





# **TRI-O Connectorboard**

At the rear all the audio in and outputs can be found, just as the euro-mains connector (with built in mains-fuse) and the optional zone outputs with the volume control inputs.



### Master stereo outputs (Cinch female)

Pin	Function	Туре
Tip	Audio +	Out
Shield	Ground	A-GND

### L/ R balanced Master Outputs (XLR 3-pins male)

Pin	Function	Туре
1	Ground	A-GND
2	Audio +	Out
3	Audio -	Out

### Tape stereo output (Cinch female)

Pin	Function	Туре
Tip	Audio +	Out
Shield	Ground	A-GND

### **Zone volume input (Cinch female)**

Pin	Function	Туре
Tip	Volume control (See page 7)	In
Shield	Ground	A-GND

### Line/ Line 1/ Line 2 Stereo inputs (Cinch female)

Pin	Function	Туре
Tip	Audio +	ln
Shield	Ground	A-GND

### Mic/ Mic Front/ Mic Rear balanced inputs (XLR 3-pins female)

Pin	Function	Туре
1	Ground	A-GND
2	Audio +	ln
3	Audio -	ln

### Phones output (TRS Jack 3p, front)

Pin	Function	Туре
Tip	Left	Out
Ring	Right	Out
Sleeve	Ground	A-GND

### Connections

### **BALANCED** MASTER L/R

Electronically balanced master outputs on XLR connectors for the left and right channels of master A. This type of output guarantees perfect signal transmission even if long audio cables are being used. These outputs are equipped with relays to prevent connected equipment from 'plopping' when the unit is being switched on and off.

### **UNBALANCED** MASTER

Unbalanced outputs on cinch connectors. These can be used to connect the Crew to an amplifier or recorder. These outputs are equipped with relays to prevent connected equipment from 'plopping' when the unit is being switched on and off.

**ZONE 1...4 Audio out** With these outputs additional zones with separate external volume control can be created. These outputs can be used to connect external amplifiers.

### **ZONE 1...4 Volume**

This input controls the volume of the additional zone. Between the tip and the shield a potentiometer or an external control voltage can be supplied. See page 7 for a more detailed explanation.

### CHANNEL 7...3

Cinch connectors for the stereo line inputs. Each channel has two identical inputs (line 1 and line 2) for CD-players, keyboards, MD-players etc. With the input-selector on the front on of the two inputs can be activated. Each input has it's own gain-trimmer at the rear.

### **CHANNEL 2**

Combined mono mic/ stereo line (or local input) channel with a balanced microphone input on a XLR-connector and a stereo line input on a cinch connector. When using an unbalanced microphone pin 1 and pin 3 must be connected to the shielding of the cable. To use a local zone input connect a Musicall MRA-2 to the 3 pin Phoenix connector using balanced microphone cable with a maximum lenght of 200m.

### **CHANNEL 1**

This channel has two electronically balanced microphone inputs on XLRconnectors (Mic Front and Mic Rear). When using an unbalanced microphone pin 1 and pin 3 must be connected to the shielding of the cable.

### MAINS/ FUSE

Euro mains-input. The TRI-O operates at 230V/ 50Hz. Fuse: 5x20mm (small), 315mA slow.

For	all	audio	cinch	connector	s:


White = Left, Red = Right

### Zone volume control

By means of this input the volume of an external zone can be adjusted. The volume control can be connected in two different ways:

### Supplying an external voltage


When a voltage is supplied between the tip and the shielding of one of the cinch-connectors the volume will be attenuated (for both the left and the right channel). When a negative voltage is supplied the signal will be amplified. The amplification ranges from +14...-80dB. The graph below shows the amplification as function of the applied voltage:



Voltage at 'volume control' (V)

### Connecting a potentiometer

It is also possible to connect a potentiometer between the tip and the shielding to one of the cinch connectors. The attenuation ranges from 0...-80dB. A 10kOhm logarithmically potentiometer gives the best results. The next graph shows the attenuation as function of the angle of rotation:



As a maximum four


additional output zones can be connected.



When an adjustable attenuation is not necessary a cinch connector with a short-circuit between the tip and shield must be connected. When the input is left open the volume will be fully attenuated.

# Microphone with TalkOver (1)

A microphone can be connected to this channel (at the front, or at the rear). The channel has a gaincontrol, a dual equaliser and an input-selector.



**GAIN** Volume preset for both the Mic Front and the Mic

Rear input.

**HIGH** High tone control.

**LOW** Low tone control.

Mic Front/Rear Input selector.

**TALKOVER** Enables or disables the TalkOver circuit. When

the button is pressed the LED lights up green and the TalkOver function is enabled. When you speak in the microphone all the other channels will be attenuated and the LED will light up red to

indicate voice-over activity.

**Fader** 60mm fader which can be used to control the


volume of this channel.

A, B, C Select the outputs where you want to use this

channel.

# Combined microphone/ line channel (2)

This channel can be used to connect a microphone or a stereo line-signal. The channel has a gain-control, inputselector and pre-fader listening (CUE).



**GAIN** Volume preset for both the microphone and the

stereo-line input.

**HIGH** High tone control.

LOW Low tone control.

Mic/ Line Input selector.

•

Enables/ disabled pre-fader listening. When the button is pressed the signal on this channel can

be heard on the headphones and is showed on the VU-meters. The master CUE LEDs will turn

off.

**Fader** 60mm fader which can be used to control the


volume of this channel.

**A, B, C** Select the outputs where you want to use this

channel.

# Stereo line input (3 ... 6)

Two stereo line inputs can be connected to this channel. Each channel has an input-selector, prefader listening and a gain-trimmer on the connectorboard.



Line 1/ Line 2 Input selector.

**CUE** Enables/ disabled pre-fader listening. When the button

is pressed the signal on this channel can be heard on the headphones and is showed on the VU-meters. The

master CUE LEDs will turn off.

**Fader** 60mm fader which can be used to control the volume

of this channel.

# Mastersection (A, B and C)

The TRI-O has 3 identical mastersections (A,B and C). Each section has a dual equaliser, balance and gain control and an after-fader-listen function.



**HIGH** High tone control.

**LOW** Low tone control.

**BAL** Determines the balance between the left and the right

channel. When in mid-position, the left and right channel

can be heard evenly loud.

**MASTER** Gaincontrol for the unbalanced stereo outputs (master

A and Master B) and the balanced stereo output

(master A only)

MASTER Switches the headphone source between master A CUE and master B. The LED indicates the source (master A

or master B). When the CUE function of an inputchannel is activated both master-CUE LEDs will be switched off, and the input-channel will be selected as

headphone source.

# **Various**




**POWER** Mains switch.

**PHONES** Headphones volume control with a stereo

headphones connector. The selected CUEsignal can be heard with the headphones (master A, master B or the inputs with the CUE

function enabled).

## **Meters**



This is an easy-to-read 2- x 12-segment LED display. The signal on the VU-meters is the signal on the headphones output (master A, master B, master C or the CUE signal).

An operating level of approximately 0dB is nominal.

# **Technical Specifications**

MONO INPUT	
MIC (channel 1 and 2)	.XLR-3 female, electronically balanced
Signal level	
Impedance	
Input noise	
Headroom	. 22 dB
STEREO INPUTS	
LINE (channel 2)	. Cinch
Signal level	.0 dB @ 600 Onm variable
Input impedance	
Input noise Channel separation	
LINE 1/ 2 (channel 36)	
Signal level	
Input impedance	
Input noise	
Channel separation	
TONE CONTROL	
EQUALISER CHANNEL 1 AND CHANNEL 2	
High	. 10 kHz ±12 dB. Shelvina
Low	
EQUALISER MASTER	,g
High	. 12 kHz ±12 dB, Shelving
Low	
OUTPUTS	
BALANCED MASTER (XLR)	+6 dB balanced/ 600 Ohm/ variable
UNBALANCED MASTER OUT.(Cinch)	
ZONE14	.0 dB unbalanced/ 600 Ohm/ variable
PHONES (6,3 mm TRS Jack)	
FREQUENCY RESPONSE	
MIC TO MASTER	. 15 Hz25 kHz -1 dB
ALL OTHER INPUTS TO MASTER	
THD + N	
GENERAL	
BUILT-IN POWER SUPPLY	
Mains voltage	.90250 VAC / 50 Hz
Power consumption	
SIZE AND WEIGHT	
Front	
Cutout	.445 x 132 mm (W x H)
Cabinet depth	
Weight	. 3.5 kg Net.